



ROOF MOUNT EXHAUST FAN SERVICE

- Check amp draw on all motor.
- Check belt and adjust tension-replace if necessary.
- Lubricate all moving parts.
- Check and adjust pulley.
- Check electrical connections.
- Check out complete exhaust fan cycle.
- Make any necessary recommendations.