



GAS HEATING SERVICE

- Check and adjust thermostat anticipator.
- Clean and adjust all safety controls.
- Clean burners and controls.
- Clean and adjust pilot assembly. (Check HSI/Pilot safety)
- Adjust burner for efficiency.
- Check for gas leaks in furnace.
- Lubricate moving parts.
- Check belt and adjust tension.
- Clean and adjust thermostat, set at desired temperature.
- Check filter and replace if necessary. (Media not included)
- Check flue pipe and draft inverter.
- Check and adjust fan and limit controls.
- Adjust gas pressure regulator.
- Check heat exchanger. (Primary and Secondary)
- Perform a CO test on the furnace and record.
- Check out complete furnace cycle.
- Make any necessary recommendations.